OLYMPUS° Stylus

ZOOM 105 DLX


INSTRUCTIONS

Before using your camera, read this manual carefully to ensure correct use.

ADVANCED TICHNICHES TECHNICHES AVANCES TECHNICAS AVANTADAS

CAMERA MAINTENANCE ENTRETIEN DE L'APPAREIL MANTENIMENTO DE LA CAMAL






Thank you for purchasing an Olympus camera. Before you start to use your new camera, please read these instructions carefully to obtain optimum performance and a longer service life from the unit.

DANGER



KEEP THE BATTERIES AWAY FROM FIRE. NEVER TRY TO DISASSEMBLE, RECHARGE, OR SHORT CIRCUIT BATTERIES. USED BATTERIES SHOULD BE TREATED AS GENERAL WASTE IN ACCORDANCE WITH LOCAL GOVERNMENT REGULATIONS.

NEVER ATTEMPT TO DISASSEMBLE THE CAMERA; IT CONTAINS A HIGH-VOLTAGE CIRCUIT.
IN CASE OF MALFUNCTION, CONSULT YOUR NEAREST OLYMPUS DEALER OR OLYMPUS SERVICE CENTER.



- Before using your camera, read this manual carefully to ensure correct use.
- We recommend that you take test shots to get accustomed to your camera before taking important photographs.

MAIN FEATURES

- Built-in 38mm ~ 105mm 3X zoom lens.
- Quartz date or time imprinting.
- Weatherproof.
- Remote control (optional).
- Versatile, easy-to-use functions include spot metering, night scene, as well as various flash modes.

Symbols used in this manual:

- Incorrect
 Next operation
- Operation order
- ① Indicator blinking

- Manual operation
- Automatic operationIndicator on
- Attention
 Depress halfway

Product shown in pictures and illustrations may be slightly different from the unit.

PREPARATIONS	Names and functions of parts Viewfinder display/LCD panel Diopter adjustment Using the strap/soft case Outline of operations Loading the battery Checking the battery Points to remember	
BASIC OPERATIONS	Loading the film Taking pictures Using the Focus Lock After Shooting Unloading the film	


ADVANCED TECHNIQUES

Jsing the flash modes	29
Auto (AutoFlash)	
.uto-S`(Red-Eye Reducing Flash)	32
OFF (Flash Override)	33
TLL-IN (Forced Activation)	34
Night Scene	35
Spot	36
Selftimer	38
Remote Control (optional)	39
Correcting the data	41
Printing the date and time	
9	

CAMERA MAINTENANCE


Questions and answers	44
Care and storage	
Caring for your weatherproof camera	48
Battery handling	
Remote control (optional) handling	52
Troubleshooting	53
Specifications	60

NAMES AND FUNCTIONS OF PARTS




- ① Zoom lever (See p. 21.)
 Zooms in telephoto.
 Zooms out wide-angle.
- Shutter release button (See p. 16.)
- 3 Selftimer/remote control button (See p. 38/39.)
- (1) Flash mode button (See p. 29.)
- ① LCD panel (Date/time indicator) (See p. 8.)
- ⑥ Flash*
- Selftimer indicator
- Strap eyeletVlewfinder
- Light sensor*
- Lens barrier
- (ii) Lens☆

Do not soil as this can cause blurred pictures. Wipe clean with a soft cloth.



- ① Quartz date mode buttons (See p. 43.)
- ⑤ Diopter adjustment dial (See p. 9.)⑥ Vlewfinder (See p. 8.)
- ① Orange lamp
- ® Green lamp® Film window
- Back cover Mid-roll rewind button (See p. 28.)
- Tripod socket
- Battery compartment cover
- Back cover release

VIEWFINDER DISPLAY/LCD PANEL



Viewfinder Display

- Close-up correction marks
 At a close distance, your
 subject must be
 positioned within the
 close-up correction marks.
 - Orange lamp
 Lights when the flash is ready to fire.
 Blinks while the flash is recharoing.
 - Green lamp Lights when the subject is in focus.
 - Blinks when the subject is not in focus.

- Autofocus mark
 Position your subject within the autofocus mark.
- LCD Panel
- Date/time indicator
 - Exposure counter (See p. 19.)
- Battery check (See p. 14.)
- ① Spot (See p. 36.)
- Selftimer/remote control (See p. 38/39.)
- Flash modes (See p. 29.)

Note: The LCD panel does not actually display all indications simultaneously as shown.

DIOPTER ADJUSTMENT

To Adjust the Viewfinder to Compensate for Near- and Far-sighted Vision

Turn the diopter adjustment dial until the viewfinder display becomes clear.

Turn to the right if you are far-sighted or to the left if you are near-sighted.

USING THE STRAP/SOFT CASE

The remote control can be stored in the pocket on the case's flap.

The soft case can also be carried on a belt.




OUTLINE OF OPERATIONS Basic Shooting Procedures





Load a battery (p. 13).


Open the back cover (p. 17).





- 3. Load the film (p. 17). (Use of ISO 400 film is recommended.)
- 4. Close the back cover. The film automatically advances to the first frame (p. 19).













- **5.** Open the lens barrier until you hear a click (p. 19).
- 6. Make sure the exposure counter on the LCD panel reads ";" (p. 19).
- 7. Press the zoom lever for telephoto or wideangle photography (p. 21).
- **8.** Place the autofocus mark on the subject you want to photograph (p. 22).










- **9.** Depress the shutter release button halfway to make sure the green lamp lights (p. 22).
- Depress the shutter release button fully to take a picture (p. 23).
- When the film reaches the end, it will automatically rewind (p. 28).
- 12. Open the back cover to remove the rewound film (p. 28).

LOADING THE BATTERY



2. Insert the new battery correctly as shown and close the battery compartment cover tightly.

- Use a 3 V lithium battery (Duracell DL 123A, Panasonic CR123A, or equivalent.)
- About 15 rolls of film can be used with one new battery, (p. 44)

Read "Battery Handling" on page 50.








CHECKING THE BATTERY

Open the lens barrier as shown until you hear a click. Check the remaining battery power.

Dissila	Mi
Display	Meaning
lights (and turns off automatically).	Battery is OK. You can shoot.
indicators on the LCD panel are displayed normally.	Battery power is low and battery should be replaced.
blinks and other indicators on the LCD panel go out.	Battery is dead and should be replaced immediately.

Note: Keep spare battery on hand when going on a long trip or a wedding or when using the camera in cold weather. Adjust the data every time the battery is replaced.

POINTS TO REMEMBER





Hold the Camera Correctly.

- Correct.
- Hold the camera firmly with both hands while keeping elbows at sides to prevent the camera from shaking.
- 2. Correct. In the vertical position, hold the camera with its flash positioned at the top.
- 3 Incorrect.

Caution:

Keep your fingers and the strap away from the lens, autofocus windows and flash. (See page 6.)





Proper Shutter Release. Practice before loading the film.

Depress the shutter release button halfway to lock the focus.

Make sure


The green lamp next to the viewfinder lights.

2. Depress the shutter release button fully to release the shutter and take the picture.

Cautions:

- Press the shutter release button gently.
 Avoid shaking the camera when pressing the shutter release button to prevent blurry pictures.

1.




LOADING THE FILM


Slide the back cover release upward to open the back cover.

Do not touch the inside of the camera, especially the lens. If there is dust or dirt on the lens, remove it with a blower brush.

2. Insert the film cartridge, making sure the film is lying flat.

Note: Use of ISO 400 film is recommended. When using non-DX-coded film, select ISO 100.





- Correct.
- Make sure the film is lying flat before closing the back cover.

- Incorrect.
- 2. Incorrect.
 If the film is not lying flat as shown, the film may not advance to the first frame.



3. Align the film leader with the mark ①, and close the back cover.

The film automatically advances to the first frame.

Make sure

The film does not overlap any of the positioning guides ② shown on the left.

4. Open the lens barrier until you hear a click.


Make sure

The exposure counter on the LCD panel reads 1.

Note:

If ξ blinks in the exposure counter, as shown on the left, the film is improperly loaded. Reload the film.







TAKING PICTURES


Open the lens barrier until you hear a click.


Make sure

The lens extends slightly, the flash pops up, and the LCD panel activates.

When the flash is held down, the two indicators next to the viewfinder blink. The camera will not activate. The display also goes out.

Release the flash to reactivate the camera.





2. Aim the camera at your subject. Use the zoom lever for telephoto or wide angle photography.

How to Use the Zoom Lever:


Telephoto:
Pull the lever to the "T" side to zoom in.

Maximum telephoto focal length: 105 mm


Wide angle: Push the lever to the "W" side to zoom out.

Maximum wide-angle focal length: 38 mm





① Autofocus mark






4. Depress the shutter release button halfway to adjust the focus.

Make sure

Focus has been correctly adjusted and the green lamp lights. Exposure also will be adjusted automatically.




5. Depress the shutter release button fully to take the picture.

The film automatically advances to the next frame.

Working Distance

The focus range of the camera is 0.6 m (2 ft) to ∞ (infinity).

When the subject is closer than 0.6 m (2 ft), the shutter will not release. (The green lamp blinks.)
When the subject is extremely close to the camera, the subject will be out of focus although the shutter releases.



Close-up Correction

① Picture frame
 ② Close-up correction marks
 ③ Image area of picture at 0.6 m (2 ft)

The viewfinder's picture frame shows the area that can be shot for subjects at ∞ . However, the picture area will move lower in the viewfinder as you get closer to the subject. At 0.6 m (2 ft), the shaded area is the actual available image area. In this case, the subject should be positioned below the close-up correction marks.

USING THE FOCUS LOCK To Avoid Taking Out-of-focus Pictures

When the main subject is not within the autofocus mark, use the focus lock.


The autofocus mark must be positioned on the subject in left case, the camera will focus on the background behind the subjects and the subjects will be out of focus.


① Autofocus mark

Position the autofocus mark -;- on your subject and press the shutter release button halfway.

Make sure

The green lamp lights.












2. Reposition your subjects in the picture frame while keeping the shutter release button depressed halfway. Then press the shutter release button fully.


Difficult Autofocus Subjects

Glossy or reflective surfaces Black objects Subjects behind glass or wire mesh Flames, smoke, etc. Sunlight or excessively bright light within the picture area

In such situation as the above, use the focus lock by focusing on a different subject at a similar distance. Then reposition the correct subject in the picture frame.

AFTER SHOOTING






Close the lens barrier slowly and carefully. The lens and flash will retract automatically.

2. Close the lens barrier completely. The display goes out.

Caution:

Do not force lens barrier closed as it will interfere with lens retraction.

UNLOADING THE FILM



The camera automatically rewinds the film when you reach the end of a roll.

After the motor stops and **E** starts blinking on the LCD panel, open the back cover and remove the film.


Notes:

- The number of exposures remaining decreases during winding.
- The final number of exposures may sometimes exceed the number of exposures specified on the film.



Rewinding the film before the end of the roll

Press the mid-roll rewind button gently with your nail, etc. Do not use an instrument with a sharp tip.



USING THE FLASH MODES

This camera has five flash modes. Select the flash mode according to your shooting conditions and needs.

How to select the flash mode:

As you press the FLASH mode button, the mode switches as shown on p.30. The selected flash mode is displayed on the LCD panel.



AUTO mode:

Automatically fires in low-light and backlit conditions.

(p. 31) AUTO-S mode:

Significantly reduces the phenomenon of "red-eye" (when a subject's eyes appear red in flash photos). (p. 32)

OFF mode:

The flash does not fire. (p. 33)

FILL-IN mode:

Fires regardless of available light, (p. 34)

mode:

Lights the subject in the foreground with a nightscene in the background. (p. 35)

Notes:

• AUTO-S will not be canceled when the power is turned off. All other modes will return to the AUTO mode.

 In the Auto, Auto-S Flash, and modes, the flash strength is automatically controlled to prevent pictures from being overexposed even when the subjects are close.

AUTO (Auto Flash)

In the Auto Flash mode, the flash will fire automatically in low-light and backlit conditions.

Make sure

The orange lamp in the upper right of the viewfinder lights when the shutter release button is depressed halfway.

W (38 mm) T (105 mm) 0.6 ~ 4.7 m (2 ~ 15.4 ft.) (2 ~ 7.9 ft.) 0.6 ~ 6.6 m (2 ~ 21.7 ft.) (2 ~ 10.8 ft.) 0.6 ~ 9.4 m 0.6 ~ 4.7 m

 $(2 \sim 15.4 \text{ ft.})$

 $(2 \sim 30.8 \text{ ft.})$

Notes:

- When the orange lamp is blinking, the flash is being recharged and the shutter release button won't release. Release your finger from the shutter release button, and wait for several seconds.
- Maximum distance is about 70% when using positive color film.


☆ Flash Working Range (with color negative film)

ISO

100

200

400



AUTO-S (Red-Eye Reducing Flash)

Significantly reduces the phenomenon of "red-eye" (when a subject's eyes appear red in flash photography).

In the Auto-S Flash mode, the camera will emit a series of low-power pre-flashes before the regular flash. This makes the subject's pupils contract, significantly reducing red-eye. Except for the pre-flashes, this mode is the same as the Auto Flash mode.

Red-eye reduction may not be effective when the subject:

- 1. Is not looking at the flash from the right front.
- Is not watching the pre-flashes.
- 3. Is too far from the camera.
- 4. Does not respond to the pre-flashes due to particular individual characteristics.

IMPORTANT: Be sure to hold the camera still until the shutter releases. It takes about one second.





OFF (Flash Override)

When you don't want the flash to fire even in the dark or when you want to shoot such subjects as fireworks.

In the Flash-OFF mode, the flash does not fire even in low-light conditions. Use this mode in situations where flash photography is not desired or is prohibited or in twilight or night scenes.

Note: Since a slow shutter speed (down to 4 seconds) is automatically selected in low-light situations when in the Flash-OFF mode, the use of a tripod is recommended to prevent blurred pictures caused by shaking the camera.



FILL-IN (Forced Activation)

When you want to fire the flash every shot.

In the FILL-IN Flash mode, the flash fires regardless of available light. For example, this mode can be used to brighten up a subject's shaded face or under artificial lighting such as back-lit, fluorescent light. Use this mode within the flash working range (p. 31). It may be hard to work under the excessively bright light.







ID NIGHT SCENETo Capture a Night Scene Beautifully

Use the Night-Scene Flash mode to properly light the subject in the foreground while leaving the background naturally lit.

Note: Since a slow shutter speed (down to 4 seconds) is automatically selected in low-light situations, use a tripod to prevent blurred pictures caused by camera shake.

Night-Scene mode cannot be used together with Spot mode.







SPOT MODE

To Focus and Set the Exposure for a Selected Area.

- Press the **3**/REMOTE button and flash mode button at the same time.
 - is displayed on the LCD panel.


 Press the ③/REMOTE and flash mode button at the same time or close the lens barrier to cancel the spot mode.

2. Position the autofocus mark - on your subject, and press the shutter release button halfway.

Make sure

The green lamp lights,

The exposure will be locked in the center of the autofocus mark.








3. Reposition your subject in the picture frame while keeping the shutter release button depressed halfway. Then press the shutter release button fully.

Exposure can be adjusted at different points from the autofocus frame using the Spot mode.



SELFTIMER To Put Yourself in the Picture

Press the ७ /REMOTE button. ७⊶ is displayed on the LCD panel.

Make sure

Use a tripod to hold the camera securely.


2. Aim at your subject, and press the shutter release button.

① 10 sec.: Selftimer indicator lights ② 2 sec.: Blinks

The shutter will be released about 12 seconds after the shutter release.

Notes:


- The focus and exposure will be locked when the shutter release button is depressed halfway.
 The selftimer is disengaged when the shutter is released.
- To cancel the selftimer after it has been activated, press the /REMOTE button again.



REMOTE CONTROL (optional)
The optional RC-100 Remote Control is required in the operation below.

Press the ७/REMOTE button. ७⊶ is displayed on the LCD panel.

After shooting, press the & /REMOTE button again to cancel the selftimer/remote control mode. Remote control operation is canceled automatically when not in use for more than about 20 minutes.






2. Aim the remote control at the camera, and press the button. The shutter will be released after about 3 seconds.

Notes:

- Use the remote control within the range shown at left.
 The camera will focus on the subject directly in front of it.
- The remote control may not work when the subject is backlit. In this case, use the selftimer.
 The remote control may not work when there is inverted fluorescent light near the camera.



Maradag

'98 121

CORRECTING THE DATA

Press the MODE button for two seconds or longer.

The year indication will start blinking.

Press the SET button to correct the year.
If you press the button once, the number on the
display will advance by 1. And if you keep it
pressed, the numbers will run in rapid
succession.










3. Press the MODE button again. The month indication will start blinking.

Repeat steps 2 and 3 to set the hour and minutes.

Note: As you press the mode button, the blinking indication changes in the order of year, month, day, hour, and minute. The data correction will be finished when the mode button is pressed again.

ONLOGIE



PRINTING THE DATE AND TIME

Choose the desired mode with the MODE button.

The mode will switch in the described order by pressing the MODE button.

The quartz date uses the same power source as the main unit. Make sure to correct the data after the battery is replaced.

The data is imprinted in the lower right of the picture. If there is something whitish or tinged with orange where the data is imprinted, the data may be difficult to read. The data may not be imprinted correctly on the frame(s) after the specified final exposure of the film.

① No data ② Year-month-day ③ Month-day-year

QUESTIONS AND ANSWERS

 Q: How long will the battery last?
 A: A new 3V lithium battery will last for roughly 15 rolls of 24-exposure film on which the flash was used on half of all the shots (determined under Olympus test conditions). If you do not use the flash and zoom very often, the battery will last much longer.

Q: Why does the flash get hot?
A: If the flash is used continuously, it may become hot. If this happens, stop using the camera for a while. Q: Can I use infrared film?


A: No, you cannot. Q: How should I clean the lens?


A: Wipe the lens gently with lens cleaning tissue that has been moistened with a small amount of lens cleaning fluid.


Q: Can I mount a filter or hood?

A: No, you cannot.

Q: What should I do when both the orange and green lamps are blinking and the camera doesn't work?A: Release your finger from the flash.










CARE AND STORAGE

- Do not leave camera in any place exposed to excessive heat, humidity, or direct sunlight for example, in a car or on the beach.
- 2. Do not expose the camera to formalin or naphthalene.
- 3. If the camera gets wet, wipe it with a dry towel as soon as possible. The salt in seawater can be especially damaging.
- Do not use organic solvents, such as alcohol or paint thinner when cleaning the camera.









- Do not leave the camera on or near a television, refrigerator, or other appliance with a magnetic field.
- Do not expose the camera to dust or sand as this could cause serious damage.
- Do not shake or shock the camera.
- Do not apply excessive force to the zoom lens.
- Please keep the camera in a well-ventilated place.
 Do not expose the camera to extreme heat (over 40°C/104°F) or to extreme cold (below -10°C/14°F). Low temperatures, even within this range, may sometimes cause deterioration in battery performance, temporarily disabling the camera.

 When transporting the camera from a cold place to a warm place or in the event of a sudden temperature change, put the camera into a plastic bag. This allows the camera's temperature to change slowly. Once the

CARING FOR YOUR WATERPROOF CAMERA








- This camera is weatherproof; however, it is not designed for underwater use. Please note the following warnings and use the camera correctly.
- ① The camera can withstand splashing water (e.g., seaside, swimming pool side, etc.)
- (2) The camera can be used in rain.
- (3) And in snow.
- (4) Do not wash the camera.





- ③ Do not submerge the camera or attempt to take pictures underwater.
- (§) Rubber gaskets are located inside the rear of the camera. Check the gaskets for wear and carefully remove any sand and dust to maintain a weatherproof seal.
- If the camera has been splashed by water, etc., clean the camera with a dry cloth as soon as possible.
- Do not touch the rubber gasket on the battery compartment cover or the rubber gasket on the camera back with excessive force. Do not remove the gaskets.
- Gaskets should be replaced after approximately three years, although they may require replacement earlier than that depending on use and wear.
- If the gaskets are damaged or need replacement, contact your nearest Olympus service center.

BATTERY HANDLING

NOTES

- When the camera is not used for an extended.
- period of time, remove the battery.
 Keep spare battery on hand when going on a long trip or to a cold area.
- Sweat, oil, and so on can prevent a battery's terminals from making electrical contact. To avoid this, wipe both terminals before loading battery.

WARNINGS

- NEVER TRY TO DISASSEMBLE RECHARGE, OR SHORT CIRCUIT BATTERY. NEVER EXPOSE BATTERY TO EXCESSIVE HEAT OR OPEN FLAMES.
- KEEP THE BATTERY OUT OF THE REACH OF CHILDREN. IF A CHILD SWALLOWS A BATTERY, CONTACT A DOCTOR IMMEDIATELY.
- USE ONE 3V LITHIUM BATTERY (DL123A OR CR123A). NEVER TRY TO DISASSEMBLE OR MODIFY ANY BATTERY OR BATTERY PACK FOR USE IN THIS CAMERA.

REMOTE CONTROL (optional) HANDLING

- The battery of the remote control cannot be replaced. The remote control unit is expendable. Order a new one from your nearby camera store or Olympus service center when it no longer transmits signals to the camera.
- Keep the remote control out of the reach of children. If a child swallows the remote control, contact a physician immediately.
- contact a physician immediately.

 Never try to disassemble the remote control.

 Never expose the remote control to excessive heat or open flame.

TROUBLESHOOTING

OPERATING PROBLEMS

The camera does not work.

① The lens barrier is not opened.

→ Open the lens barrier completely. (P. 20)

② The alignment of the battery terminals is not correct. → Reload the battery correctly. (P. 13)

(3) The battery is exhausted.

→ Replace the battery with new one. (P. 14)

The battery is temporarily unable to function because of cold.

→ Keep the camera warm while using it.

⑤ The loaded film has been rewound.→ Remove the film. (P. 28)

The film is incorrectly loaded.

→ Reload the film. (P. 17)

① The flash is held with your finger.→ Release your finger.

The LCD display goes off suddenly.

① If you don't use the camera, the LCD goes off after four and half minutes.

→ Close the lens barrier and open it again or operate the zoom lever to turn the LCD back on. In addition, the power is turned OFF automatically after 4 hours. When the camera is not in use, try to keep the lens barrier closed.

The shutter release button doesn't release when the remote control's shutter release button is pressed.

1) The remote control hasn't been used in the 20 minutes since the Selftimer/Remote Control mode was engaged, causing the LCD panel to turn off.

→ Press the zoom lever. The LCD will light. Then press the Selftimer/Remote button again.

The green lamp blinks, and the shutter release button will not release.

The camera is closer than 0.6 m (2 ft.) to the subject.
 → Move the camera back to distance more than 0.6 m (2 ft.) from the subject. (P. 23)

The orange lamp blinks, and the shutter release button will not release.

The flash has not been recharged yet.
 → Remove your finger from the shutter release
 button and wait for several seconds until the flash is
 recharged before shooting. (P. 31)

The flash does not fire, even in the dark.

- ① The flash mode is set to OFF.
- → Set it to a mode other than OFF. (P. 29)
- ② High sensitivity film is being used.→ Set the flash mode to FILL-IN. (P. 29)

The viewfinder is out of focus.

① Diopter dial is not adjusted.
 → Adjust the diopter dial until image is clear. (P. 9)

PROBLEMS WITH PRINTED PICTURES

The picture is out of focus. ① The camera moved when the shutter release button

was pressed. → Hold the camera correctly and press the shutter release button gently. (P. 15)
 ② The subject was not within the viewfinder's

autofocús mark.

→ Position the subject in the center of the autofocus mark, or use the focus lock. (P. 22)

The lens and autofocus windows were dirty.

→ Clean the lens and autofocus windows.

The autofoous window was blocked, such as by a finger.

→ Hold the camera correctly, keeping your fingers clear of the autofocus windows. (P. 15)

(§) The subject was closer than the minimum working distance to the lens (0.6 m/2 ft.).

→ Shoot from more than 0.6 m (2ft.) away from the subject. (P. 23)

(§) When using the selftimer, the shutter release button was pressed while standing right in front of the camera.

→ Do not stand in front of the camera. Press the shutter release button while looking through the viewfinder. (P. 38)

- ① The autofocus didn't work correctly. There are some subjects that are difficult for the autofocus to lock on. These include: glossy or reflective surfaces, black objects, subjects behind glass or wire mesh, flames and smoke, excessively bright light within the picture area.
 - → First focus on an object at the same distance as the desired subject. Then aim at the desired subject and release the shutter release button. (P.36)

The picture is too dark.

- 1 The flash was blocked, (e.g. by a finger).
 - → Hold the camera correctly, keeping your fingers clear of the flash. (P. 15)
- ② The subject was out of the working range of the flash. → Shoot within the flash working range. (P. 31)
- → Shoot within the flash working range. (P. 3°)

 The flash mode was set to OFF.
 - → Check the flash mode before shooting. (P. 29)

The data has not been printed (or looks faded).

The data mode was set to no data (---).
 → Change the data mode to another setting.

(P. 43)

- ② There is a bright color like white, orange, or yellow in the area of the picture where the data is printed. → Avoid bright colors in the lower right comer of your photo compositions. (P. 43)
- The picture was taken with black-and-white film.
 → Do not use black-and-white film if you want to print data on the pictures.
- The camera's battery is low.
 - → Replace with a new battery. (P. 13)

The color of a picture taken indoors is abnormal.

① The color of the room lighting affected the picture.

→ Set the flash to FILL-IN mode.

SPECIFICATIONS

Type: Full automatic 35 mm autofocus lens-shutter camera with built-in 38 ~ 105 mm zoom lens. Film format: 35 mm standard DX-coded film (24 x 36 mm)

Lens: Olympus lens 38 ~ 105 mm F4.5 ~ 8.9, 6 elements in 5 groups.

Shutter: Programmed electronic shutter. Viewfinder: Real image zoom viewfinder (with autofocus mark, close-up correction marks, autofocus indicator and flash indicator).

Focusing: Active-type autofocus system. Fócus lock possible. Focusing range: 0.6 m (2 ft.) ~ ∞ (infinity).

Exposure control: Programmed automatic exposure control, 3-zone light metering, switchable to spot metering. Auto exposure range: Wide-angle — EV2.3 (F4.5, 4 sec.) to EV16 (F10.9, 1/500 sec.), Telephoto — EV4.3 (F8.9, 4 sec.) to EV17 (F19.7, 1/350 sec.).

Exposure counter: Progressive type with automatic reset, displayed on LCD panel.

Selftimer: Electronic selftimer 12-sec. delay.

Remote control (optional): Infrared remote control unit with 3-sec. delay.

Film speed range: Automatic setting with DX-coded film with ISO 50, 100, 200, 400, 800, 1600, 3200. For non DX-coded film and film with less than ISO 50, film speed is set to ISO 100.

Film loading: Automatic loading. (Automatically advances to first frame when camera back is closed.)

Film advance: Automatic film winding.

Film rewind: Automatic film rewind (automatic rewind activation at end of film, automatic rewind stop). Rewind possible at any point with rewind button.

Flash: Built-in flash. Recycling time: Approx. 0.5 ~ 7 sec. (at normal temperature with new battery). Flash working range: Wide-angle — 0.6 ~ 4.7 m (2 ~ 15.4 ft.), Telephoto — 0.6 ~ 2.4 m (2 ~ 7.9 ft.) with ISO 100 color negative film: Wide-angle — $0.6 \sim 9.4 \text{ m}$ (2 ~ 30.8 ft.). Telephoto — $0.6 \sim 4.7 \text{ m}$ (2 ~ 15.4 ft.) with ISO 400 color negative film. Flash modes: AUTO (Automatic flash activation in lowlight and backlight), AUTO-S (Red-eye reducing, otherwise same as auto), OFF (No flash), FILL-IN (Forced activation), (for night scene with slowest shutter speed of 4 sec. Other functions operate as the same as in Auto mode.) Battery check: Displayed on LCD panel.

Weatherproof: IEC Standard publication 529. Classification of degrees of protection provided by enclosures. Degree of protection indicated by the second characteristics numeral 4. • Short description: Protected against splashing water. Definition: Water splashed against the enclosure from any direction shall have no harmful effect. • Test for second numeral 4: The equipment is sprayed from all practical directions. The water pressure is adjusted to give a delivery rate op 10 lit./min. The test duration shall be 1 min. per m2 of calculated surface area of the enclosure with a minimum duration of 5 min. Power source: 3 V lithium battery (DL123A/CR123A) Dimensions: 120 (W) x 64 (H) x 44 (D) mm (4.7 x 2.5 x 1.7 in) (without protrusions). Weight: 240 g (8.5 oz) (without battery).

SPECIFICATIONS FOR DATE UNIT Imprinting direction: Data imprinted onto film from lens side.

Data coding: No data, year-month-day, month-dayyear, day-month-year and day-hour-minute. External indication of data: Data display on LCD panel. Film speed setting: Automatic film speed setting. Automatic calendar system: Up to year 2030. Power source: Ordinarily used with camera body.

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT ANY NOTICE OR OBLIGATION ON THE PART OF THE MANUFACTURER.

OLYMPUS°

OLYMPUS OPTICAL CO., LTD.

San-Ei Building, 22-2, Nishi Shinjuku 1-chome, Shinjuku-ku, Tokyo, Japan. Tel. 03-3340-2211 OLYMPUS AMERICA INC.

Two Corporate Center Drive, Melville, NY 11747-3157, U.S.A. Tel. 516-844-5000 OLYMPUS OPTICAL CO.(EUROPA) GMBH.

(Premises/Goods delivery) Wendenstraße 14-16, 20097 Hamburg, Germany. Tel. 040-237730 (Letters) Postfach 10 49 08, 20034 Hamburg, Germany.

OLYMPUS OPTICAL CO. (U.K.) LTD.

2-8 Honduras Street, London EC1Y 0TX, United Kingdom, Tel 0171-253-2772